


# Terminal Type Installation Guide


## Single Stage Power Settings (Standard)

Standard Fin PTC Air Heaters are designed for single stage heating (full power). Multiple power settings are available upon request. Refer to the illustrations below for standard wiring of MH, MSH, SH and TH type Fin PTC Air Heaters:


MH & MSH Type:



SH & TH Type:



Example 1 – Standard **Single** Insulation Wiring – Part Number: MH-2130S-93S4



Example 2 – Standard **Double** Insulation Wiring – Part Number: MH-2120S-93D4

