
Fin PTC Air Heaters 33


## **Wired Type Installation Guide**

## **Single Stage Power Settings (Standard)**

Standard Fin PTC Air Heaters are designed for single stage heating (full power). <u>Multiple power settings are available upon request</u>. Standard wiring illustrations of MHW, MSHW, SH and TH type Fin PTC Air Heaters are shown below:



Example1 - Standard Wiring - Model: MHW-2130S(B/N)-93S(D)4 & SHW-2040M(B)-70S(D)4



Example 2 - High Ampere Wiring - Model: MHW-1200S(B/N)-93D(S)4 & SHW-1080M(B)-70S(D)4

